ICE CRUSHER

MODEL: MIC-A109



1.Operation

① Check voltage of current wether or not it corresponds to the shown and required voltage. Power supply should be with reliable ground wire.

② Pick-up press-ice handle to up stop point, plug into electricity. Turn on main switch, lie down the ice disc under Chassis, put down ice granular into the ice smash drum.

(NOTE:quantity of ice in the drum can not exceed level of ice smash drum) Then put down the handle of the ice smash drum, to make protect switch to turn on auto matically, get the result of the smash ice, after finish work. Please raise the handle of ice smash to the up-stop,then to repeat above-mentioned procedurer.

2.Clean & maintenance

After operation of smash ice device, should turn off switch.Put out electricity plug.Wipe the surface of device to dry and lie it at the dry place.

3.Caution

When operation,outlet of ice granular can not be blocked,other words,knife disc will be blocked,destroy motor,if above appearance appear, please lift up handle immediately,turn off source of electricity, examine the Reason.

NOTE: To improve our product continously, The factory hold the right of change above technical parameter with out notice.

4.Techmical parameter

Voltage: 220V-240V	Input: 350W
Frequency: 50-60Hz	Own Weigt: 8kg
Device size: 400x180x310mm	Speed: 1400r/min
Packaging size: 425x205x320mm	Quantity of smash ice:65kg/hr