

47449 / PC1870B

Position	ItemNo	Description
00	52041	Light Switch Green
02	47594	Upper Left Hinge
03	47595	Connecting Piece
04	47596	Upper Right Hinge
05	55703	Circlip type C
06	47599	T-type Nylon Gasket
07	47600	Upper Door Shaft
08	47562	Door Gasket Long
09	47563	Door Gasket Short
10	52807	Door Handle Black
11	55677	Hinge Connector
12	52808	Glass Door w/ Black Handle LH
	55684	Glass Door w/ Black Handle RH
13	47564	Door Gasket Long
14	52809	Side Panel Right, Black RAL9005
15	55678	Side Panel
16	52811	Side Glass
17	52813	Front Grill, Black RAL9005
18	47565	Digital Thermostat Carel
20	55679	Junction Box
22	52804	LED Driver
23	52806	Relay
24	52805	LED Driver
25	47579	Condenser
26	47602	Lower Right Hinge
27	46053	Fan Blade
28	47569	Fan Motor
29	47820	Compressor K480DU
30	47581	Condenser Pipe
31	47582	Drip Tray
32	47583	Filter Drier
33	47584	Door Stopper
34	55680	Hexagonal Set Screw
35	47585	Door Spring Stopper
36	47586	Door Spring
37	47571	Door Spring Right
	47572	Door Spring Left
38	47601	Lower Left Hinge
39	47603	Upper Door Shaft Sleeve
40	47604	Lower Door Shaft
41	47587	Castors
	47616	Legs
43	52810	Side Panel Left, Black RAL9005
44	55681	Air Return Grill
45	47589	Bottom Shelf
46	47608	Evaporator
47	47591	Shelf Bracket
48	47606	LED Light
49	47609	Price Holder 40mm
50	67810	Shelf Stand / Shelf LED Support
51	47610	Shelf
	67812	Shelf Assembled
52	55683	Ventilation Cover

47449 / PC1870B

