

48872 / FSC891H

| Position | ItemNo | Description                    |
|----------|--------|--------------------------------|
| 01       | 54918  | Door Complete                  |
| 02       | 14374  | Evaporator Cover               |
| 03       | 54935  | Right Glass Door Complete      |
| 04       | 54919  | Door LED Light                 |
| 05       | 13556  | Finger Guard                   |
| 07       | 13483  | Fan Blade 200 mm               |
| 08       | 12864  | Hinge Bush                     |
| 09       | 15515  | Holder For LED Strip           |
| 10       | 54928  | Left Glass Door Complete       |
| 11       | 54433  | Bottom Hinge Right             |
| 12       | 54917  | Compressor EHU6214U            |
| 13       | 38539  | Condenser Maintenance Free     |
| 14       | 41007  | Fan Axial                      |
| 15       | 13357  | Condenser Fan Bracket 72 mm    |
| 17       | 54920  | Drip Tray                      |
| 18       | 13321  | Condenser Clip                 |
| 19       | 34734  | Dryer                          |
| 20       | 11218  | Rear Grill                     |
| 21       | 35098  | Wire Shelf With Print Profile  |
| 22       | 13756  | Plastic For Door Switch        |
| 23       | 16619  | Door Switch Black Warsteiner   |
| 24       | 13802  | Carel Thermostat Easy          |
| 25       | 35353  | Cover For Thermostat           |
| 26       | 11243  | Cover For Screw                |
|          | 54936  | Screw Plug                     |
| 27       | 14618  | Roller                         |
| 28       | 54910  | Bottom Grill                   |
| 29       | 14899  | Clip For Shelf                 |
| 30       | 11359  | Back Side Spacer               |
| 31       | 14565  | Adjustable Foot                |
| 32       | 12728  | Base For Hinge                 |
| 33       | 54916  | Canopy Light Plate             |
| 34       | 12563  | Door Gasket                    |
| 35       | 12819  | Door Spring Left               |
| 36       | 12820  | Door Spring Right              |
| 36B      | 10715  | Lock With Keys                 |
| 37       | 54914  | Canopy Base                    |
| 38       | 15671  | Power Supply 4 Sides Glass LED |
| 39       | 54911  | Bracket for Door Switch        |
| 40       | 12850  | Bottom Hinge Left              |
| 41       | 54924  | LED 7000K 4,37W                |
| 42       | 38644  | Evaporator Fan Complete        |
| 43       | 12700  | Handle Curved Black            |
| 44       | 54921  | Evaporator                     |
| 45       | 12852  | Bottom Hinge Right             |
| 46       | 13519  | Fan Motor                      |
| 47       | 13441  | Evaporator Fan Frame           |
| 53       | 13488  | Fan Blade 25 cm (Condenser)    |
| 80       | 52599  | Thermostat Cover               |

2025-10-21

48872 / FSC891H

