

20104 / FS1202S/UK

Position	ItemNo	Description
01	11299	Top Panel
02	15477	Socket For Starter
03	15484	Starter 4-65 W
04	15339	Ballast 36W
	15627	LED Power Supply
05	13838	Control Panel Sheet
07	13519	Fan Motor
08	13439	Evaporator Fan Frame
09	13556	Finger Guard
10	13483	Fan Blade 200 mm
11	14309	Evaporator
12	14371	Evaporator Cover
13	14065	Thermostat XR06CX 20A Relay Red Display
	14066	Thermostat XR06CX 20A Relay Blue Display
14	13896	Probe NTC Dixell/Carel 10 Kohm
16	13737	Light Switch
17	15378	Internal Tube Cover
18	14898	Clip For Shelf
20	15224	Wire Shelf For P. Strong
21	14897	Bottom Wire Shelf
22	11217	Rear Grill
23	14524	Heat Exchanger
26	14613	Nut For Roller
27	14570	Adjustable Foot
28	14618	Roller
29	14610	Bolt For Roller
30	11186	Middle Support
31	43348	Bottom Panel Hexagonal For Light Switch
34	15721	Filter Drier 20 G
37	11774	Compressor NEU6214U R290
	11827	Compressor GPY16RAA R134
38	13529	Fan Motor Div. Use/Condenser
39	13488	Fan Blade 25 cm (Condenser)
40	14083	Condenser
41	11478	Drip Tray
43	10993	Frame Profile Side 2013
44	10991	Frame Profile Bottom
45	15344	Clip For Light Cover
46	15354	Cover For Vertical.FI.Tube
47	15369	Fluorescent Tube 36W
	15637	LED Strip 1200 mm - 6500k
	46191	1155mm LED Strip 6500K 13LM
48	15372	Fluorescent Tube Holder
	35362	LED Plastic Clips
49	15471	Socket Flourescent Tube Canopy
51	11889	Cover For Door Ramps
52	12129	Door Ramp
53	34430	Glass Door sliding w/lock Left 2021
53B	10715	Lock With Keys
54	34419	Glass Door sliding w/lock Right 2021
55	14611	Circlip For Rollers
56	12157	Door Roller
57	11874	Bearing For Sliding Doors
58	14620	Shaft For Roller
59	11958	Door Bracket For Rollers Right
62	12167	Door Spring
63	11957	Door Bracket For Rollers Left
71	11243	Cover For Screw

20104 / FS1202S/UK

73	12163	Door Sealing
80	52599	Thermostat Cover

2026-04-20

20104 / FS1202S/UK

